

Slot Track Scenics – Instructions for painting and fitting Loudspeakers (LS1)

What you will need :

- **A sharp knife for trimming the parts off the sprue.** *(This is because it would have added greatly to the cost to have them trimmed off for you.)*

What to do.

1. Trim all the 6 parts off one sprue. Pole, cross beam, 2 x Speaker back, 2 x Speaker cone. See Picture 1. DO NOT trim the pins off the speaker backs!
2. Carefully press the cones on to the backs so that they hold them but are not fully engaged. Then press the speakers on to the cross beam, the cross beam on to the pole and the pole into the clip converter – if you are not putting the pole directly into a wood base. (See Picture 2.)
3. Decide where you want to have the speakers and work out how high you want them to be. If using our clips (for Plastic track or wood) take these into account. Remove the cross beam and cut the pole to the desired height. Re-assemble the cross beam on the (shortened) pole.
4. Repeat steps 1 to 3 for the remaining speaker assemblies.
5. Start by painting the speaker cones in your chosen colour. Leave to dry. Then remove them from the speaker backs and paint those and the cross beam. Leave to dry and then remove from the pole while you paint the pole. Leave to dry. See Pics. 3 and 4.
6. Re-assemble and push into the clips that you fixed around your track while you were waiting for the paint to dry! (See Picture 5.)

Picture 1



Picture 2



Picture 3

Picture 4

Picture 5

